

ROEWE/MG

ROEWE

Immobiliser

350

-2012

Add a key

Erase keys

2013-

Add a key

Erase keys

360

Add a key

Erase keys

550

-2012

Add a key

Erase keys

Remaining unlock time

2013-

Add a key

Erase keys

Remaining unlock time

950

With smart

All smart keys lost

Add a smart key

Erase DTC

Live data

Without smart

All keys lost

Erase DTC

Live data

W5

Type 1

Add a key

Erase keys

Type 2

Add a key

Erase keys

Remote

750

Program remote

Position 1

Position 2

2016.05.15

- Position 3
- Position 4
- Position 5
- Read remote ID
 - Position 1
 - Position 2
 - Position 3
 - Position 4
 - Position 5
- Disable remote
 - Position 1
 - Position 2
 - Position 3
 - Position 4
 - Position 5
- Enable remote
 - Position 1
 - Position 2
 - Position 3
 - Position 4
 - Position 5
- Erase DTC
- MG
 - Immobliser
 - GS
 - Program smart key
 - Erase smart key
 - GT
 - Add a key
 - Erase keys
 - Remaining unlock time
 - MG3
 - Add a key
 - Erase keys
 - Remaining unlock time
 - MG5
 - Add a key
 - Erase keys
 - Remaining unlock time
 - MG6
 - 2012
 - Add a key
 - Erase keys
 - Remaining unlock time

2013-

- Add a key
- Erase keys
- Remaining unlock time

MG7

2013-

- Add a key
- Erase keys
- Remaining unlock time

Remote

MG3(Old model)

- Program remote
- Erase remotes
- Read emergency password
- Read VIN

MG7

Program remote

- Position 1
- Position 2
- Position 3
- Position 4
- Position 5

Read remote ID

- Position 1
- Position 2
- Position 3
- Position 4
- Position 5

Disable remote

- Position 1
- Position 2
- Position 3
- Position 4
- Position 5

Enable remote

- Position 1
- Position 2
- Position 3
- Position 4
- Position 5

Erase DTC